

# C-Bus<sup>®</sup>

## C-Touch Colour Touch Screen Nail Bracket

### 5000CTCNA

Series

### Installation Instructions

#### Installation Instructions

The C-Touch Colour touchscreen nail bracket (part number 5000CTCNA) provides a convenient means of mounting the C-Touch Colour unit. The nail bracket (illustrated in Figure 1) is used where it is practical to nail or screw the nail bracket into a wall frame.




Figure 1 - Nail Bracket

#### Overall external dimensions

Width – 285mm

Height – 215mm

Depth – 47mm

## To mount the nail bracket

- 1) Place the bracket against a beam of the wall frame.
- 2) Position flush with beams and frame towards front.
- 3) Nail the bracket into the frame. Alternatively mark and drill the holes, then screw the bracket into the frame.
- 4) Feed the cables through to the nail bracket. The use of conduit is recommended. Refer to Figure 2. The number and positioning of cables will vary depending on the particular installation.




Figure 2. Nail Bracket Cabling

### Internal Cutout Dimensions

Width – 205mm

Height – 162mm

---

#### Clipsal Australia Pty Ltd

A member of Schneider Electric

Contact us: [clipsal.com/feedback](http://clipsal.com/feedback)

National Customer Care Enquiries:

**Tel 1300 2025 25**

**Fax 1300 2025 56**

**clipsal.com**

Clipsal Australia Pty Ltd reserves the right to change specifications, modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© Clipsal Australia Pty Ltd. The identified trademarks and copyrights are the property of Clipsal Australia Pty Ltd unless otherwise noted.