

Installation Guide Hemispherix AS



Your Krix speakers are designed to reproduce the highest quality sound. To get the best performance from your speakers please read these installation instructions thoroughly as there are many factors that influence the performance of your speakers. If you have any difficulties please contact one of our friendly authorised Krix dealers.

installation


before you begin



Please read the disclaimer on the back of this manual.

Discuss with your local Krix distributor, or installation consultant, to determine the best location for your loudspeakers. Be sure to check for any obstructions, such as electrical wiring, plumbing, stud work or air conditioning ducts before commencing the installation. (figure 1)





Also ensure that there is enough ceiling space to accommodate the speaker enclosure.

connecting

To ensure optimum performance it is important that your speaker system is connected properly:



Turn off all electronic equipment and disconnect from the power point.

- Follow the connection instructions supplied with your amplifier, CD/DVD, hard disk recorder, video player etc.
- Install speaker cable in wall or ceiling cavity, or run cable along wall surface. Allow approximately 300mm of excess cable to facilitate loudspeaker installation.
- Follow the connection instructions supplied with your amplifier to connect the speaker cables to amplifier. Take care to assign the same cable colour or trace to the positive (+) connector on the amplifier as the positive (+) connector on the speaker.
- Prepare speaker cables for connecting to speakers by neatly stripping cable ends.




Care should be taken to eliminate loose strands of wire that may be present a short circuit hazard.

installation


- Once the correct placement of the speakers has been determined, use the cardboard insert marked 'template' (from the internal packing) to trace the required cut-out onto the ceiling/wall. (figure 2)
- Drill a hole inside the marked cut-out. Using a fine gyprock saw, cut around the inside of the marked cut-out. (figure 3)
- Remove the circular offcut and insert the speaker to check the hole is the correct size. Enlarge the cut-out if required.
- Pull the stripped speaker cable through the ceiling opening. Push and hold down the positive (+) red binding post on the speaker and insert the positive (+) wire through hole in post. Take care to assign the same cable colour or trace to the positive (+) connector on the amplifier, as the positive (+) connector on the speaker. Repeat connection process with the negative (-) black binding post and the negative (-) wire. (Figure 4)
- Ensure all mounting clamps are swung back against the speaker enclosure (Figure 4), so that the speaker can be easily inserted into the ceiling cut-out. Once the speaker has been located in the ceiling/wall, use a Philips head screwdriver to tighten all mounting screws. As the screws are tightened, the mounting clamps will automatically swing out over the gyprock and clamp the speaker in place. Be careful not to over tighten the screws, as this may strip the clamp, or crush the gyprock surface. (Figure 5)
- The Hemispherix AS features a pivoting tweeter which allows the high frequency sound to be directed as desired, depending on your environment and preference. Gently press on the round outer edge of the tweeter frame to tilt the tweeter to the desired position. Be careful not touch the tweeter diaphragm, as this may damage to the tweeter. (Figure 6)
- Gently fit the magnetic grille to the front of the speaker housing. (Figure 7)



/!\ If the grille requires painting it is recommended that the grille is painted attached to the speaker after installation. Use a small foam roller with a light coverage of thin paint to avoiding blocking the holes in the grille.



installation





Krix Loudspeakers Pty Ltd 14 Chapman Road Hackham SA 5163 Australia

T 61 8 8384 3433 F 61 8 8384 3419 listen@krix.com

Rev #10006

krix.com



/!\ disclaimer

All warranties, conditions, representations, promises and statements relating howsoever to this product whether express or implied and

Our liability to you under a condition or warranty (if any) implied into this sale and purchase agreement relating to this product by the Trade Practices Act 1974 (as amended) or any other law (whether a law of Australia or any other country) other than a condition implied by Section

If you do not accept the above conditions, return this product (in the original packaging) with proof of purchase for a full refund.